



*Focusing
Channel numbers*

28 & 114

29 & 115

32 & 118

1, 2 & 101

26 & 27

3,4 & 102

30 & 116

16,17 & 109

15 & 108

5,6 & 103

31 & 117

24,25 & 113

22,23 & 112

18, 19 & 110

13,14 & 107

7,8 & 104

20,21 & 111

11,12 & 106

9,10 & 105



FÖRRAD

ö2

KONTROLLRUM

ö4

KONTROLLRUM

ö3

ENTRESOL

ö1

BRANDGRÄNS

BEF. LASTPORT

T-RUM

ö6